

# RESTROOM INDICATOR LATCH

## Specifications

<b>Door Installation:</b>	Interior Latch: Four - 7/64-in x 1/2-in deep pilot holes and one 1/2-in hole in marked center
	Interior Strike: Two 7/64-in x 1/2-in deep pilot holes
	Exterior Trim: Two 5/64-in x 1/2-in deep pilot holes
<b>Mounting:</b>	Surface Mounted with Spindle
<b>Door Thickness:</b>	3/4-in minimum
<b>Hardware:</b>	Six - #7 x 1-in sheet metal screws #4 x 19/32" sheet metal screws
<b>Material:</b>	Latch - SUS 201 Colored Indicator - Plastic Hardware - SUS 201
<b>Required Tools:</b>	Pencil, #2 Phillips Screwdriver, Drill, 1/2" and 1/16" Drill Bit and 7/64-in drill bit
<b>UL:</b>	No
<b>Colored Indicator:</b>	Green (Vacant) Red (Occupied)
<b>ADA Compliant:</b>	No



## Dimensions

